

Laminated Exam Tables

Models:

CCI8020, CCI8020-FH, CCI8020-AB, CCI8020-R

Assembly Instructions

Install Leg-

- Lay tabletop frame on flat surface with metal corner brackets flush to the flat surface.
- On each end of table insert a laminated leg with levelers facing up. **Note:** Brackets are loose on top frame to allow for proper aligning of holes.
- Secure legs to the end of the table frame by placing 1 $\frac{1}{4}$ " fender washers onto the $\frac{1}{4}$ " x 3 $\frac{1}{2}$ " bolts. Insert bolts with fender washer through the two outer holes on the end of the table. Place $\frac{1}{4}$ " flat washer on to the bolt and secure with $\frac{1}{4}$ " lock nut.
- Place 1 $\frac{1}{4}$ " fender washer on to a $\frac{1}{4}$ " x 3 $\frac{1}{2}$ " bolt and insert through center hole of the leg. Place 1 $\frac{1}{4}$ " fender washer on to bolt and secure with $\frac{1}{4}$ " locking nut. Tighten the five bolts then tighten bolts on the side of table.
- Once all bolts are tightened the brackets, legs, and top frame should be flush on the flat surface.

Install Shelf-

- Align brackets on shelf with holes in leg. Place 1 $\frac{1}{4}$ " fender washer on to $\frac{1}{4}$ " x 2" bolt and insert through hole. Place $\frac{1}{4}$ " flat washer on to bolt and tighten with $\frac{1}{4}$ " lock nut.

Install Table Top:

- Turn exam table upright and place padded top on to the frame. Place $\frac{1}{4}$ " flat washer on to $\frac{1}{4}$ " x 1" bolt and insert bolt through bracket and into tabletop. Tighten bolts and adjust levelers as needed.